

# Regency Finials PVC 11"

Fit the Radius End Cap to the ridge section.

Ensure both sections - the crest retaining upper section and the lower ridge section finish flush and that you have attached the top crest retaining profile onto its base ridge section.

Slide into the top crest retaining section your selection of crests – for PVC you might have to trim one down in size allowing enough space (65mm) for the base of the finial to be pushed home into the crest retaining profile.

Check that the top of the finial base aligns with the crest you are using you might have to remove some material from the top of the finial base connecting flange in order to have a uniform alignment between finial base and crests.

Drill a 2.5mm hole into the top flange of the crest retaining profile and into the base of the finial flange - screw in the stainless steel retaining screw-your finial assembly is now firmly retained.



## Price

£18.37 (Product reference 2417-0)

A discount of 5% has been applied for the use of All Customers